



ENTRE//MATIC



ALTA7EH

IP2115EN- rev. 2010-07-27



Installation and
maintenance manual
for automations
for sliding gates.

(Translation of the original instructions)



DITEC S.p.A.

Via Mons. Banfi, 3 - 21042 Caronno Pertusella (VA) - ITALY

Tel. +39 02 963911 - Fax +39 02 9650314

www.ditec.it - ditec@ditecva.com

ISO 9001
Cert. n° 0957

INDEX

Subject	Page
1. General safety precautions	3
2. Declaration of incorporation of partly completed machinery	4
2.1 Machinery Directive	4
3. Technical data	5
3.1 Operating instructions	5
3.2 Dimensions	6
4. Standard installation	7
5. Main components	8
6. Mechanical installation	9
6.1 Position of base plate	9
6.2 Geared motor installation	10
6.3 Gearmotor height adjustment	10
6.4 Rack installation	11
7. ALTASF photocell support installation	12
8. SOFA-SOFB safety edge installation	13
9. Electrical connections	14
10. Routine maintenance plan	14
11. Operating instructions	15
12.1 General safety precautions	15
12.2 Manual release instructions	16

CAPTION



This symbol indicates instructions or notes regarding safety issues which require particular attention.



This symbol indicates informations which are useful for correct product function.



This symbol indicates instructions or notes intended for technical and expert personnel.



This symbol indicates operations not to be effected for not compromise the correct operation of the automation.



This symbol indicates options and parameters which are only available with the indicated item.



This symbol indicates options and parameters which are not available with the indicated item.

All right reserved

All data and specifications have been drawn up and checked with the greatest care. The manufacturer cannot however take any responsibility for eventual errors, omissions or incomplete data due to technical or illustrative purposes.

1. GENERAL SAFETY PRECAUTIONS



This installation manual is intended for professionally competent personnel only.

Installation, electrical connections and adjustments must be performed in accordance with Good Working Methods and in compliance with applicable regulations.

Before installing the product, carefully read the instructions. Bad installation could be hazardous. The packaging materials (plastic, polystyrene, etc.) should not be discarded in the environment or left within reach of children, as these are a potential source of hazard.

Before installing the product, make sure it is in perfect condition.

Do not install the product in an explosive environment and atmosphere: gas or inflammable fumes are a serious hazard risk.

Before installing the motors, make all structural changes relating to safety clearances and protection or segregation of all areas where there is risk of being crushed, cut or dragged, and danger areas in general.

Make sure the existing structure is up to standard in terms of strength and stability. The motor manufacturer is not responsible for failure to use Good Working Methods in building the frames to be motorized or for any deformation occurring during use.

The safety devices (photocells, safety edges, emergency stops, etc.) must be installed taking into account: applicable laws and directives, Good Working Methods, installation premises, system operating logic and the forces developed by the motorized gate.

The safety devices must protect any areas where the risk exists of being crushed, cut or dragged, or where there are any other risks generated by the motorized gate.

Apply hazard area notices required by applicable regulations.

Each installation must clearly show the identification details of the motorized gate.



Before making power connections, make sure the plate details correspond to those of the power mains.

Fit an omnipolar disconnection switch with a contact opening gap of at least 3 mm.

Make sure an adequate residual current circuit breaker and overcurrent cutout are fitted upstream of the electrical system. When necessary, connect the motorized gate to a reliable earth system made in accordance with applicable safety regulations.

During installation, maintenance and repair, interrupt the power supply before opening the lid to access the electrical parts.



To handle electronic parts, wear earthed antistatic conductive bracelets. The motor manufacturer declines all responsibility in the event of component parts being fitted that are not compatible with the safe and correct operation.

For repairs or replacements of products only original spare parts must be used. The installer shall provide all information relating to automatic, manual and emergency operation of the motorized gate, and provide the user with operating instructions.

2. DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY

(Directive 2006/42/EC, Annex II-B)

The manufacturer DITEC S.p.A. with headquarters in Via Mons. Banfi, 3 - 21042 Caronno Pertusella (VA) - ITALY declares that the automation system for ALTA7EH sliding gates:

- has been constructed to be installed on a manual gate to construct a machine pursuant to the Directive 2006/42/EC. The manufacturer of the motorized gate shall declare conformity pursuant to the Directive 2006/42/EC (annex II-A), prior to the machine being put into service;
- conforms to applicable essential safety requirements indicated in annex I, chapter 1 of the Directive 2006/42/EC;
- conforms to the Low Voltage Directive 2006/95/EC;
- conforms to the Electromagnetic Compatibility Directive 2004/108/EC;
- technical documentation conforms to annex VII-B to the Directive 2006/42/EC;
- the technical file is managed by Renato Calza with offices in Via Mons. Banfi, 3 - 21042 Caronno Pertusella (VA) - ITALY;
- a copy of technical documentation will be provided to national competent authorities, following a suitably justified request.

Caronno Pertusella, 27-07-2010

Silvano Angaroni
(Managing Director)



2.1 Machinery Directive

Pursuant to Machinery Directive (2006/42/CE) the installer who motorises a door or gate has the same obligations as the manufacturer of machinery and as such must:

- prepare the technical file which must contain the documents indicated in Annex V of the Machinery Directive; (The technical file must be kept and placed at the disposal of competent national authorities for at least ten years from the date of manufacture of the motorized gate);
- draft the EC declaration of conformity in accordance with Annex II-A of the Machinery Directive and deliver it to the customer;
- affix the CE marking on the power operated gate in accordance with point 1.7.3 of Annex I of the Machinery Directive.

3. TECHNICAL DATA

	ALTA7EH
Power supply	230 V~ / 50-60 Hz
Absorption	1,5 A
Thrust	600 N
Wing speed	0,12÷0,20 m/s
Maximum run	20 m
Max wing weight	600 kg
Service class	4 - INTENSE
Intermittence	S2 = 30 min S3 = 50%
Temperature	-20 °C / +55 °C
Degree of protection	IPX4D
Control panel	EL31R


3.1 Operating instructions

Service class: 4 (minimum 10÷5 years of working life with 100÷200 cycles per day).

Applications: INTENSE (for condominium, industrial and commercial entrances, parking spaces with intense vehicle or pedestrian access).

- Performance characteristics are to be understood as referring to the recommended weight (approx. 2/3 of maximum permissible weight). When used with the maximum permissible weight a reduction in the above mentioned performance can be expected.
- Service class, running times, and the number of consecutive cycles are to be taken as merely indicative. Having been statistically determined under average operating conditions, and are therefore not necessarily applicable to specific conditions of use.
- Each automatic entrance has variable elements such as: friction, balancing and environmental factors, all of which may substantially alter the performance characteristics of the automatic entrance or curtail its working life or parts thereof (including the automatic devices themselves). The installer should adopt suitable safety conditions for each particular installation.

3.2 Dimensions




L = 1200 [ALTA7EH12]
1600 [ALTA7EH16]



NOTE: unless otherwise specified, all measurements are expressed in millimetres (mm).

4. STANDARD INSTALLATION




Ref.	Code	Description
1	ALTA7EH	Motor + control panel
2	LAMPH	Flashing light
3	XEL5 LAN4 LAN7	Key selector switch Combination keyboard Card decoder
4	GOL4	Radio
5	XEL2 LAB4 LAB4S XELCB	Photocells Photocell column
6	SOFA-SOFB LAB4AV GOPAV	Safety edge Infrared system for safety edges Radio system for safety edges
7	LAB9	Magnetic loop detection device for traffic monitoring
A		Connect the power supply to an approved omnipolar switch with an opening distance of the contacts of at least 3mm (not supplied). The connection to the mains must be made via an independent channel, separated from the connections to command and safety devices.



NOTE: the given operating and performance features can only be guaranteed with the use of DITEC accessories and safety devices.

5. MAIN COMPONENTS



Ref.	Code	Description
1		Geared motor
2		Lock release lever
3		Motor height adjustment screw
4		Control panel
5		Cable gland
6		Pinion
7		DIN rail for accessory module support
8	CROSSCRI CROSSCRN2	Rack
9	ALTASF	LAB4 photocell support

6. MECHANICAL INSTALLATION

Check the stability of the wing (derailing and lateral falls) and the sliding wheels and that the upper guides do not cause any friction.

The sliding guide must be securely fixed to the ground for the full length within the doorway and must have no irregularities that could hinder the movement of the gate.


The opening and closing stops must be fitted.

NOTE: make sure that the gate can not exit the sliding guides and fall.

If the gate has slits, make sure they are covered to prevent shearing points.


Safety device should be installed at the end of the wing to reduce the collision force.

6.1 Position of base plate




- Insert the anchor brackets onto the base plate and fix them with the supplied nuts.
- Make a concrete base with the anchor brackets and base plate embedded, which must be level and clean, following the measurements indicated in the figure.
- If the concrete base is already present, fix the gearmotor with expansion bolts (not supplied) that can withstand a thrust of at least 600 N.

6.2 Geared motor installation




- Unlock the gearmotor (see OPERATING INSTRUCTIONS).
 - Place the gearmotor onto the base plate.
 - Level the gearmotor by adjusting the headless screws [1].
 - Horizontally adjust the gearmotor by sliding the gearmotor on the slots of the anchor brackets.
- NOTE: for the vertical adjustment, keep the gearmotor slightly raised from the base plate so that the rack can be fixed and subsequent adjustments are possible.*

6.3 Gearmotor height adjustment




- Unlock the gearmotor (see OPERATING INSTRUCTIONS).
- Loosen the motor plate securing screws [1].
- By adjusting the screw [2] place the motor plate at the correct height so that the pinion [4] acts correctly on the rack [5].
- Fix the motor plate by tightening the securing screws [1].
- Confirm the height of the motor plate by turning the support nut [3] until it reaches the correct height.

6.4 Rack installation




- Unlock the gearmotor (see OPERATING INSTRUCTIONS) and open the gate.
- Rest the rack [1] on the pinion [2] and by manually sliding the gate, fix it along its entire length.
- Once fixing is complete, vertically adjust the gearmotor so that there is a clearance of 2-3 mm between the pinion [2] and the rack [1].
- Lock the gearmotor.
- Slightly lubricate the rack [1] and pinion [2] after assembly. Manually check that the gate slides evenly and without friction.

7. ALTASF PHOTOCELL SUPPORT INSTALLATION



Install the ALTASF photocell support and the LAB4 photocell as shown in the figure.
NOTE: check that the external photocell is correctly aligned with the internal photocell.

8. SOFA-SOFB SAFETY EDGE INSTALLATION



9. ELECTRICAL CONNECTIONS

The electrical connections and start-up are illustrated in the installation manual of the EL31R control panel.
WARNING: connect the yellow-green earth wire to the appropriate terminal already connected to the motor.

10. ROUTINE MAINTENANCE PLAN

Perform the following operations and checks every 6 months according to intensity of use of the automation.

Disconnect the 230 V~ power supply and release the gearmotor:

- Visually check that the gate, the fixing brackets and existing structure have suitable mechanical strength and are in good condition.
- Check the gate-gearmotor alignment, the distance (2-3 mm) between the throat of the pinion and the crest of the rack.
- Clean the wheel's sliding guide, the rack and pinion of the gear motor and slightly lubricate the rack and pinion of the gearmotor. Manually check that the gate slides evenly and without friction.

Reconnect the 230 V~ power supply and block the gearmotor:

- Check the power adjustment.
- Check that all control and safety functions are working correctly.




NOTE: for spare parts, see the spares price list.



DETACH AND DELIVER TO THE CUSTOMER

11. OPERATING INSTRUCTIONS



11.1 General safety precautions

The following precautions are an integral and essential part of the product and must be supplied to the user. Read them carefully since they contain important information on safe installation, use and maintenance. These instructions must be kept and forwarded to all possible future users of the system.

This product must only be used for the specific purpose for which it was designed.

Any other use is to be considered improper and therefore dangerous. The manufacturer cannot be held responsible for any damage caused by improper, incorrect or unreasonable use.

Avoid operating in the proximity of the hinges or moving mechanical parts.

Do not enter within the operating range of the motorized gate while it is moving.

Do not block the movement of the motorized gate since this may be dangerous.

Do not allow children to play or stay within the operating range of the motorized gate.

Keep remote controls and/or any other control devices out of the reach of children in order to avoid possible involuntary activation of the motorized gate.

In the event of fault or malfunctioning of the product, turn off the power supply switch, do not attempt to repair or intervene directly and contact only professionally competent personnel.


Failure to comply with the above may cause a dangerous situation.

All cleaning, maintenance or repair work must be carried out by professionally competent personnel.

To ensure that the system works efficiently and correctly, the manufacturer's indications must be complied with and routine maintenance of the motorized gate must be performed by professionally competent personnel.


In particular, regular checks are recommended in order to verify that the safety devices are operating correctly.

All installation, maintenance and repair work must be documented and made available to the user.

 For the correct disposal of electric and electronic equipment, waste batteries and accumulators, the user must take such products to the designated municipal collection facilities.



DETACH AND DELIVER TO THE CUSTOMER



11.2 Manual release instructions

In the event of a fault or power failure, open the cabinet hatch and release the gearmotor by turning the lock release lever as shown in the figure.

Open the gate manually.

To block the gate again, move the lock release lever back into position and close the cabinet hatch.

WARNING: carry out the door wing blocking and release with the motor switched off.



DITEC S.p.A.
Via Mons. Banfi, 3
21042 Caronno Pertusella (VA) - ITALY
Tel. +39 02 963911 - Fax +39 02 9650314
www.ditec.it - ditec@ditecva.com

Installer:



DITEC S.p.A. Via Mons. Banfi, 3 21042 Caronno P.Illa (VA) Italy Tel. +39 02 963911 Fax +39 02 9650314
www.ditec.it ditec@ditecva.com

DITEC BELGIUM LOKEREN Tel. +32 9 3560051 Fax +32 9 3560052 www.ditecbelgium.be **DITEC DEUTSCHLAND** OBERURSEL
Tel. +49 6171 914150 Fax +49 6171 9141555 www.ditec-germany.de **DITEC ESPAÑOLA** ARENYS DE MAR Tel. +34 937958399
Fax +34 937959026 www.ditecespanola.com **DITEC FRANCE** MASSY Tel. +33 1 64532860 Fax +33 1 64532861 www.ditecfrance.com
DITEC GOLD PORTA ERMESINDE-PORTUGAL Tel. +351 22 9773520 Fax +351 22 9773528/38 www.goldporta.com **DITEC SWITZERLAND**
BALERNA Tel. +41 848 558855 Fax +41 91 6466127 www.ditecswiss.ch **DITEC ENTREMATIC NORDIC** LANDSKRONA-SWEDEN
Tel. +46 418 514 50 Fax +46 418 511 63 www.ditecentrematicnordic.com **DITEC TURCHIA** ISTANBUL Tel. +90 21 28757850
Fax +90 21 28757798 www.ditec.com.tr **DITEC AMERICA** ORLANDO-FLORIDA-USA Tel. +1 407 8880699 Fax +1 407 8882237
www.ditecamerica.com **DITEC CHINA** SHANGHAI Tel. +86 21 62363861/2 Fax +86 21 62363863 www.ditec.cn