



INSTALLATION MANUAL Installation manual

version 1.0



Dear customer,

Congratulations on the purchase of the product $2N^{\circ}$ OMEGA 48. This new product was developed and manufactured with an emphasis on maximum user value, quality and reliability. It is our desire that the $2N^{\circ}$ OMEGA 48 should give you complete and long satisfaction.



CONTENT

1. Basic module	<u> 5</u>
Description of parts of basic module	<u> 7</u>
2. Description of mechanical parts	7
2.1. Base (chassis)	7
2.2. PBX cover	8
3. Description of electrical components	<u> 9</u>
3.1. Motherboard	9
3.3. Source – mains part ringing transformer	. 12
3.4. Display	14
Other separate components	15
4. Extender module up to 12 ports (order No 1880010)	15
5. Extender module up to 24 ports (order No. 1880011)	16
6. Interface modules	17
6.1. Module 2x internal line (order No 1880030)	18
6.2. Module 2x system telephone (order No 1880039)	19
6.3. Module 2x system telephone – digital (order No. 1880038)	21
6.4. Module 1x external line / 1x internal line (order No 1880031)	22
6.6. Module GSM 900/1800/1900 Mbz pro 1-2 GSM	23
6.7. Module ISDN S ₀ (Order No 1880020)	. 25
6.10. Module VoIP (Order No 1880021)	27
7. Detailed installation	28
7.1. Selection of place for PBX	28
7.2. Unpacking and checking	29
7.3. Installation of extender module up to 12 lines	29
7.5. Installation of Line modules.	. 30
7.6. Installation of VoIP module	31
8. Mounting PBX on wall	41
8.1. Earthing PBX	41
8.2. Connection to mains network	42
8.3. Cabling for connecting system telephones	42
0. Minor convicing tasks	42
9. Millior servicing tasks	4 <u>3</u> 43
9.2. Setting music volume	.43
10. Expanding PBX	44
11. Installation of front-end protection	44
12 Technical parameters	<u>45</u>
12. reciment putuleero	15





1. Basic module



Types of basic modules

- **1880002** basic module without modem for RemoteSupervision up to 48 lines
- 1880003 basic module with modem for RemoteSupervision up to 48 lines



In its assembled state, each basic module contains these parts:

- chassis (metal part of mechanism) with power source
- display
- plastic cover
- motherboard with or without modem for remote supervision (RS)
- extender module up to 24 lines
- 1x platelet for power cable
- 2x blanking platelets

The following components are included:

- Wall-mounting element (part of basic module)
- Rawlplugs and screws for wall mounting
- Power cable
- Screws for fixing serial or blanking platelets

It also contains this equipment:

- CD with complete documentation and necessary SW
- Serial cable with RJ-12 terminal and one gender changer for DB-9 connector
- Cable for Data connection between main board and 24 ports Extender module
- Cable for connection of power supply voltage between main board and 24 ports Extender module



Description of parts of basic module

2. Description of mechanical parts

2.1. Base (chassis)

The base carries the other parts. The power supply (plug 110 - 230V/AC + power switch) is mounted in the upper right part. The upper left + lower left part is intended for fitting the extender. The strip with holes in the bottom part is intended for fitting serial and blanking platelets. The display is fixed in the upper part in the centre.





2.2. PBX cover

The plastic cover bears a sticker with a transparent window for the display. The cover is fitted on the chassis by fitting into two holes in the upper part of the plastic and is secured by two extendable "pegs" into the lower part of the plastic. When dismantling the cover, first press (using an appropriate tool) both extendable "pegs", whereby you free the cover and then remove the cover.





3. Description of electrical components

3.1. Motherboard





B1	- Lithium battery holder. We recommend replacement when the voltage is lower than 2.5 V, or at least once every three years. We recommend the batteries be replaced with the PBX off. Before replacement we recommend saving the program of the PBX and the accounting data in a PC. After replacement check the date, time and program of the PBX and, if not correct, make the correct adjustment. Never change the batteries when the PBX is on.
J1	- connector for connecting extender
J2 – J7 J8 – J9	 connectors for connecting line modules (description of modules – see Chapter 5) shorting jumpers (connected – RS232-COM is connected to the J18 connector, disconnected – RS232-COM is connected to the module VoIP)
J10	- company's servicing reanimation connector (1 Hz)
J11	- connector for connecting additional memory for announcements (180 s)
J12	- shorting jumper – always fitted (activation WATCH DOG)
J13 .114	- company's servicing reanimation connector (SW for ALTERA)
J15	- connector for connecting VoIP module
J16	connector for connecting LED signalling
J17	- connector for display
J18	- connector RJ12 with galvanic isolation for PC connection (RS232-COM).
J19 J20	- Input voltage connector – $(1, \pm 5^{\circ}, 2, 4, GND, 3, \pm 24^{\circ}, 5, \pm 24^{\circ}, 6, KING^{\circ})$.
J21	- output voltage connector – (+24V DC).
J22	- input voltage connector – (+24V DC).
J23	 shorting jumper – always disconnected (only for testing purposes – connection GND and PGND),
J24 J25	 servicing connector (locking of FLASH memory). line input (CINCH – AUX IN) for connecting external music source (for example CD, radio).
SW1 SW2	 Auxiliary RESET1 button (pressing results in reset). Auxiliary RESET2 button (1. –setting company values (press button + switch on PBX + confirm by pressing again after display of message "Clear config? - push again/wait", 2. entry to "service mode" (hold button down during test of RAM memory).
P1	- regulating volume of line input.
U1 U2-3	 governing processor connecting cross-point array.
D1 D2 D3	- signalling +5V - signalling -12V - signalling +12V
Connecting up connector RJ-12 (J18)	1 - RTS 2 - TXD 3 - GND 4 - GND 5 - RXD 6 - CTS



Note:

J18 – the connector is intended for connecting the PBX with a PC. It thus allows the programming of the PBX using the program OMEGA 48 - PROGRAM, detailed display of operation using program OMEGA 48 - PANEL, for connection of XAPI Server, etc.

The serial port includes an insulating DC/DC converter of its own and, by optical signal transmission, provides galvanic isolation of the serial port from the PBX with a guaranteed insulation strength of 500 V.

This solution has the following advantages:

- Helps transmit data over long distances
- Improves data transmission reliability (resistance to disruption)
- Enables communication with a PC powered from a different power supply section (for example, from a different phase or central UPS)
- Improves overvoltage resistance of the input

For connection with a PC, especially over a greater distance, a normal (i.e., crossover) four-wire telephone cord with RJ-12 terminals is normally used instead of a special "serial cable".



3.2. Power supply

As the **Power supply** a power supply module with open construction and with output voltage of +24VDC/2.7A (connector J2) is used. One integral part of the supply is the cooler, which is designed for an upright working position of the PBX. It is not allowed to operate the PBX in a horizontal position (lying on a table etc). The source is distinguished in particular by the simplicity of connection, which is a guarantee of the source's maximum reliability. The source has an overvoltage fuse (F1) F4A/250V. The power goes to connector J1.



3.3. Source – mains part _ ringing transformer

The mains part is attached using a detachable mains lead (so-called EURO socket).





The lever switch located on the right side of the chassis serves for switching the power on and off.



The mains part is protected against contact with live parts by a cover which also covers the actual power source.

The ringing voltage with a frequency of 50 Hz comes directly from the mains by a so-called ringing transformer. The ringing transformer is protected from shorting by fuse T0.063A.

WARNING! This part is connected to the mains power and works with voltage which



is dangerous to life. All repairs and replacements of these parts are only made at the manufacturer!! Only the following handling is allowed:

Mains lead connection and disconnection

Always perform this handling with the PBX disconnected from the mains!!!



!!! Note: The source can be connected to equipment of the type UPS (backup source).



3.4. Display

The LCD display is fitted on an independent holder and connected by means of a flat cable to the motherboard. It displays the current version of the PBX firmware, the date, time and data about state of line.





Other separate components

4. Extender module up to 12 ports (order No 1880010)

The extender module is intended for mounting in the basic PBX module. It enables the extension of the PBX by 12 lines (6 modules with interfaces) + insert 1 module AUDIO IN/OUT intended for example for the system IVR, automatic operator, recording of calls,...



J1	- connector for connecting motherboard.
J2 – J7	- connectors for connecting line modules (description of individual modules – see Chapter 5).
J8	- connectors for connecting module AUDIO IN/OUT (module intended for applications: <i>automatic operator, IVR, VoiceMail,</i>).
U1	- connecting cross-point array



5. Extender module up to 24 ports (order No. 1880011)

Extender module is mounted in the basic module of a PbX. It enables to extend PBX for other 24 ports

It is mounted to second level chassis by seven screws M3 (are include in package). Extender module needs to be connected with main board using the DATA and power supplying cable (both of cables are includes in package)



J1	- Conn	ector	r for I	DATA	cable
	 _				

- J4 J15 Free slots for line mudules
- J2 J3 Conector for power supplying
- D1 control LED.
- D2 control LED.



6. Interface modules

Order No	Name of module	Internal designation 2N	Total number
1880030	Module 2x internal line	OL2VL	24
1880038	Module 2x system digital	OL2SYSD	10
1880039	Module 2x system telephone	OL2SYS	10
1880031	module 1x external line / 1x internal line	OCOVL	24
1880032	module 1x external line receiver 16kHz / 1x internal	OCOVL16	24
1880041	module GSM 1x MC55	OL2GSM	6
1880042	module GSM 2x MC55	OL2GSM	6
1880043	module GSM 1x MC56	OL2GSM	6
1880044	module GSM 2x MC56	OL2GSM	6
1880020	module ISDN S ₀	OLISDN	6
1880021	Module VoIP	OLIP8	1

General features

A line module generally contains two interfaces. One exception is the module S_0 , which contains one interface (but which carries two calls at the same time) and combined module of external and internal line. Modules are equipped with overvoltage protection and can be fitted to the motherboard or extender module in any order. All modules are equipped with an identification system allowing the program of the PBX to ascertain the concrete configuration immediately after switching on. All module connectors contain two pairs of blanked holes (without contacts). This measure prevents the incorrect insertion of modules.

All modules can be fitted up to the maximum number of vacant positions (12 = 6 motherboard + 6 extender module).

RJ45 connectors for connecting local circuits are a part of line modules. The module is secured against movement by a screw in the connected strip.



6.1. Module 2x internal line (order No 1880030)

The internal line interface works with a line voltage of 24V and **line** current of approximately 30 mA. It is **symmetrical**, which guarantees good resilience against line cross-talk. The nominal impedance is 600 Ω . The module allows caller identification (Caller ID – CLIP). This module supports the receipt of identification using DTMF between the first and second ring.



- J1 connector for connecting to motherboard (or to extender module) (connector is secured against incorrect connection by the blanking off of PIN 5,6,7,8)).
 J2 connector RJ-45 (PIN 4,5) for connecting analogue external line
- J2 connector RJ-45 (PIN 4,5) for connecting analogue external line (PORT 1).
- **J3** connector RJ-45 (PIN 4,5) for connecting analogue external line (PORT 2).
- D1 signalling LED (busy, ringing on VL PORT 1).
- D2 signalling LED (busy, ringing on VL PORT 2)



6.2. Module 2x system telephone (order No 1880039)

This is a four-wire interface, which must be respected for designing circuits around the building. The conductors A-B used for call transmission are without DC potential. The conductors C-D serve for data transmission and also supply the system telephone with voltage -24V. Both pairs are strictly symmetrical, which minimises rf radiation and also ensures good resistance to line cross-talk. When the RJ-45 connector is connected, A-B represents the internal pair and C-D represents the external pair.





J1	- motherboard connector (or for extender module (the connector is ensured against incorrect connection by the blanking of PIN 5,6,7,8).
J2	- connector RJ-45 (A-B = PIN 4-5, C-D = PIN 6-3) for connecting system line (PORT 1).
J3	- connector RJ-45 (A-B = PIN 4-5, C-D = PIN 6-3) for connecting system line (PORT 2).
J4	- company's servicing reanimation connector (SW for ALTERA).
D1 D2	 signalling LED (communication SYS PORT 1). signalling LED (communication SYS PORT 2).



Notes:

- In no case may system telephones be connected in parallel.
- LEDs (D1,D2) on the module signal by flashing ongoing communication between the PBX and system telephone.
- If the C and D connectors are confused in the system cabling, the system telephone will not work but will not be damaged.
- The module is provided with its "own intelligence" a processor that time balances the data flow between the main PBX processor and both system telephones. This single-chip microcomputer is mounted in a socket and can be replaced if necessary.



6.3. Module 2x system telephone – digital (order No. 1880038)

Module for the connection of two digital system telephones 2N StarPoint. When connecting to the RJ-45 connector, pins 4, 5 are used and the order of the conductors in the pair is not emphasized.



J1 - connector for connection to the main board (or the extension module - if applicable (the connector is secured against incorrect connection by deactivation of PIN 5,6,7,8)).

- **J2** connector RJ-45 (PIN 4-5) for connection of a digital system line (PORT 1).
- **J3** connector RJ-45 (PIN 4-5) for connection of a digital system line (PORT 2).
- J4 company maintenance recovery connector.
- J5 company maintenance recovery connector.
- **D1** LED signaling (communication SYS PORT 1).
- D2 LED signaling.
- **D3** LED signaling.
- **D4** LED signaling (communication SYS PORT 2).

Notes:

It is possible to insert maximum of 20 modules in the PBX and serve 460 programming buttons.

Flashing LEDs (D1, D4) on the module indicate communication between the PBX and the digital system telephones connected.

Flashing LEDs (D2, D3) on the module indicate preparedness of the module for connection of the digital system telephones



6.4. Module 1x external line / 1x internal line (order No 1880031)

Combined module for connecting one analogue external (J2) and one analogue internal line (J3). The module allows the receipt of caller identification (Caller ID – CLIP) using FSK modulation.

In the event of a power failure of the PBX, the module is equipped with a spill relay which ensures the direct connection of the analogue external line to the internal.



- J1 connector for connecting to motherboard (or extender module (the connector is secured against incorrect connection by the blanking of PIN 5,6,7,8).
- J2 connector RJ-45 (PIN 4-5) for connecting analogue external line.
- **J3** connector RJ-45 (PIN 4-5) for connecting analogue internal line.
- **J4** company servicing reanimation connector (SW for ALTERA).
- **J5** connector for setting impedance (1-2= ETSI, 2-3= 600Ω).
- **D1** signalling LED (picking up, ringing external line).
- **D2** signalling LED (picking up, ringing internal line).
- T1 -CO transformer

Note:

• Equipment attached to connector J3 (telephone) must comply with the requirements (standard – type approval) for equipment connected to the unified telephone system.



6.5. Module 1x external line/1xinternal line with 16 kHz tariff pulse receivers (order No1880032)

This module is completely identical with the previous one but also contains a 16 kHz tariff pulse receiver (T2). The frequency and sensitivity of the receivers are set precisely and optimally by the manufacturer. The set sensitivity is approximately -30 dB. Sensitivity can be reduced by removing jumper J1 to approximately -10 dB. Reducing sensitivity would make sense, for example, if tariff pulses were received from another line (cross-coupling) or in the case of strong interference (industrial converters, high-power TV equipment etc.). The LED on the module indicates the receipt of tariff pulses.



- J1 connector for connecting to motherboard (or to extender module (connector is secured against incorrect connection by the blanking off of PIN 5,6,7,8).
- J2 connector RJ-45 (PIN 4-5) for connecting analogue external line.
- **J3** connector RJ-45 (PIN 4-5) for connecting analogue internal line.
- J4 company servicing reanimation connector (SW for ALTERA).
- **J5** connector for setting impedance (1-2= ETSI, 2-3= 600Ω).
- **D1** signalling LED (picking up, ringing external line).
- **D2** signalling LED (picking up, ringing internal line).
- T1 -CO transformer.
- T2 -16kHz transformer.

Note:

• Equipment connected to connector J3 (telephone) must comply with the requirements (standard – type approval) for equipment connected to the unified telephone system.



6.6. *Module GSM* 900/1800/1900 Mhz pro 1-2 GSM

Order No 1880041 – for 1 GSM connection MC55/MC55i Order No 1880042 – for 2 GSM connection MC55/MC55i Order No 1880043 – for 1 GSM connection MC56/MC55i Order No 1880044 – for 2 GSM connection MC56/MC55i

The module GSM is fitted in a free position like any other interface and is intended for connecting one or two lines to the GSM network.

For the module with two GSM lines, both connected GSM work independently. An independent SIM card must be inserted for each line SIM (the SIM card holder is attached to the platelet of the GSM module GSM).

The basis for the GSM module is an industrial triband GSM module SIEMENS MC55 (or MC56 – triband USA).

Only one antenna with an SMA connector is attached to the GSM module (located on the module platelet).



J1	- connector for connecting to motherboard (or extender module) (connector is secured against incorrect connection by the blanking off of PIN 5,6,7,8).
J2	- connector for connecting GSM module Siemens MC55/55i/56 (PORT 2).
J3	- connector for connecting GSM module Siemens MC55/55i/56 (PORT 1).
J4-J5 J6	 connector for inserting SIM cards (SIM1/SIM2) company servicing reanimation connector (SW do CPU).
D1 D2 D3	- signalling LED (login, GSM fault- PORT 1). - signalling LED (login, GSM fault - PORT 2). - signalling LED (power of module).



The GSM module makes it possible to:

- automatically make calls to the GSM network and thus significant reduction in telephone bill of your firm.
- receive incoming calls and, in connection with the DISA code distribute them to the branches (analogue internal lines, system lines).
- When calls are made to the GSM network, to utilise all the services of the PBX (reconnecting call, conference, rerouting, CLIP-called number display and its entry on record).

In the current form the module **does not** make it possible to:

- convert a fax GSM connection to an analogue fax connected to the PBX,
- convert a data GSM connection to an analogue modem connected to the PBX.

6.7. Module ISDN S₀ (Order No 1880020)

The module contains two four-wire interfaces BRI or 2B+D (1x ISDN input, 1x ISDN BUS), and so two calls can pass through it simultaneously. It is intended for connecting to the public ISDN network and supports connection in the regime PTP and PTMP.

- In the regime PTP (Point to Point) the code DDI is supported (i.e., as many sequential numbers as the user requests of the ISDN provider). It is not possible to attach any further ISDN equipment to the line. The advantage is the possibility of merging capacity – when several ISDN modules are fitted they can all have the same code.
- In the regime PTMP (Point to MultiPoint) MSN is supported (i.e., upon request it is possible to allocate up to eight numbers, but it need not be a continuous series of numbers). It is possible to connect further ISDN equipment to the line (for example, ISDN card in computer – one number, on the module up to seven numbers will remain).

We recommend that overvoltage protection be installed to prevent destruction of the ISDN module by overvoltage.

The control program of the module is stored in a FLASH memory which enables the updating of the program directly in the PBX.

One of the input RJ45 connectors can be used for simpler creation of an ISDN bus and thus for the connection of further ISDN equipment (ISDN telephone, fax, modem).





- J1 connector for connecting to motherboard (or extender module) (connector is secured against incorrect connection by the blanking off of PIN 5,6,7,8).
 J2 connector for connecting ISDN line from equipment ISDN NT (end
 - connector for connecting ISDN line from equipment ISDN NT (end point).
- J3 connector ISDN BUS.
- J4-J5 jumpers terminating ISDN line using terminating resistances of 100Ω (connected used for termination of ISDN lines under the assumption that this ISDN line will end in this point (for example, always for type PTP)) !!! NOTE under the assumption that the terminating resistances are not already ISDN socket!!!
- J6 . company servicing reanimation connector.
- J7 . company servicing reanimation connector.
- **J8** company servicing reanimation connector (SW for CPU).
- **J9** company servicing reanimation connector (SW for ALTERA).
- **D1** signalling LED (synchronisation of layer 1).
- **D2** signalling LED (synchronisation of layer 2).
- **D3** signalling LED (occupying of channel B1).
- signalling LED (occupying of channel B2).
- **D5** signalling LED (power of module on).



6.8.

6.10. Module VoIP (Order No 1880021)

The VoIP Module is designed exclusively for $2N^{\otimes}$ OMEGA 48 PBXs as a VoIP module for LAN and Internet voice services.

The VoIP Module is to be installed to the left from the power supply unit, above the main board. To connect the module, use the two connecting cables packed in the separate plastic bag (insert them to the J15/J26 connectors on the main board) and the two spacers (also packed in the separate plastic bag). Use the remaining two M3 screws to screw the VoIP Module to the spacers.

Remove the two J8/J9 links on the PBX base plate for appropriate operating efficiency.

Use the USB cable and the hyper-terminal for the initial setting of the IP address and the network mask; use the (available) web configuration for further settings.

The system connects to the 10/100BASE-T (Twisted Pair Ethernet) computer network through a standard direct cable with RJ 45 connectors at the end.

See the VoIP Module User Manual on the enclosed CD for detailed installation information.



The following is located on the VoIP module:

- J1 RJ45 connector 8/8 for LAN connection.
- J2 USB connector for USB connection, designed for IP configuration.
- J4,J8 serial connector designed for connection with the main board of the PBX.



J3 - connector for the connection of adapter for an external USB device (USB FLASH disk)*.

J5-J7 - connector for maintenance use

J9 - connector for connection of a functional floor*

SW2 - RESET button. Pressing this button will RESET the CPU board.

SW1 - RESET button. Pressing this button will reset default values (after switching on the PBX hold the button pressed for approximately 20s until LINUX starts).

D1 - green LED – operation status indication (VoIP module ready for operation, approximately 20s after light-up).

D2 - red LED – operation status indication (VoIP module inactive). D3-D10 - yellow LED – call channels busy signal.

* In preparation **Detailed installation**

7.1. Selection of place for PBX

Aspects which must be taken into consideration when selecting a place for the PBX:

- Good visibility and accessibility (the exact time and other data about operation is shown in the display of the PBX in operation).
- Protection from damp and extreme temperatures: the PBX must definitely not be located near heat sources (above heaters) or in a place where direct sunlight may fall. Also avoid damp places (bathroom, cellar), places where the temperature changes rapidly (near doors, windows, air-conditioning), dusty places (workshops etc) or places with aggressive gases (battery rooms, boiler rooms) and places with high vibrations and shocks (compressors, heavy industrial operations). The PBX has an upright operating position.
- Installing circuits in building: by choosing a suitable location for the PBX (centre of building or administrative centre) it is possible to reduce the costs for the building of the circuits. If there are already circuits in the building, the location of the PBX is generally already determined thereby and it cannot be changed.
- Possibility of direct connection using modules with connectors RJ-45.
- Quality of GSM signal: if one part of your configuration is (or later will be) a GSM module, it is necessary to take into account the fact that the cable from the PBX to the GSM cable is usually about 3 metres long (maximum 10m). It is therefore necessary to make sure that in the specified circuit around the selected place for the PBX there is a place with a good level of GSM signal suitable for locating the GSM antenna. *)
- Ensuring against theft: when selecting a position, it is recommended that the conditions of the insurance company be respected.
- Opening cover: there should be at least 10 cm of free space right and left of the PBX.



Note: In places with a poor level of GSM signal it is possible to use an independent (external) GSM gateway which can be installed at a distance of up to 500 m from the PBX (!) in a place with a good GSM signal (on high building, hill etc.) and ensure both cheap access to the GSM network and reliable function in places where there is very poor coverage (borderline areas).

7.2. Unpacking and checking

If you haven't yet done so, check that the delivery is complete. The packaging of the basic module is usually used for the transport of other independently purchased items of the PBX (modules etc.). You can usually check them using the delivery note and order numbers which are on all parts. The remaining components in the upper part of the box are the accessories of the basic module. Remove the separate basic module from the upper part. Open it and check everything against the packing sheet, which is a separate annex to the documentation. Check whether there was any mechanical damage to the parts during shipping. On the top of the box there is a printed reinforcing piece which serves as a drilling template for the mounting of the PBX. Keep the packaging (especially from the extender modules).

7.3. Installation of extender module up to 12 lines

First connect an extender module (extender) using connector J1 with the motherboard (connector J1) and then affix it to the chassis of the basic module using six screws.





7.4. Installation of extender module up to 24 lines

As the first an extender module fix with seven screws to basic chassis, then connect DATA and power supplying cable between main board (connectors J19, J27) and extender bard (connectors J1, J2, J3).



7.5. Installation of Line modules

Note: All modules can be fitted separately even after the PBX is mounted on the wall, but it is more comfortable to fit them on a table.

Line modules can be fitted in any position on the motherboard (connectors J2-J7) or extender module (connectors J2-J7).



7.6. Installation of VoIP module

Remove the display holder by unscrewing 2 screws on the chassis.



Remove by turning the end cap on the left-hand side of the chassis for J1 and J2 connectors.



Installation manual www.2n.cz



Remove 2 JUMPERs, J8/J9, from the main board.



Unscrew 2 M3 screws from the left and right corner of the main board (these will be used for fixing of the VoIP module) and replace them with the spacers attached.











Insert the two connectors attached into the J26 and J15 connectors on the main board.







Place the VoIP module onto the connectors inserted and fix it with two screws.





Place the module onto the connectors carefully to avoid shifting of the individual PINS.













Connect the USB cable inserted (into J2 connector) and connect it with your PC.



When connecting for the first time it is necessary to install USB-COM driver (on the "data/2N OMEGA 48/VoIP/DriverUSB/" CD attached). A new COM PORT is added after installation. After this you may connect by hyper-terminal and perform the necessary settings.



COM4 - vlastnost	ti		? ×
Nastavení portu	1		
	1		1
<u>B</u> ity za se	ekundu: 115200		
Date	vé bity: 8		
	<u>P</u> arita: Žádná	_	
Dežetet			
Pocet st	op-bitů: [1		
Říze	ní tokur. Hardware		
11128		·	



Serves for network parameter setup (IP address/network mask,.). After the network parameters have been set up you may disconnect.



Always RESET the module using the SW1 button after disconnecting the USB cable.

Connect a standard direct Ethernet cable into the J1 connector.



This cable connects the VoIP module with your Ethernet network. After turning the PBX power on you may start configuring the VoIP module.

TELEKOMUNIKACI



8. Mounting PBX on wall

Using the drilling template (on scale 1:1), mark two holes on the wall (for requirements for location see above, paragraph Selection of location for PBX). Using an 8 mm masonry bit, drill holes and put rawlplugs in them. Screw the hanging element of the PBX into the upper holes using two screws (it is fixed to the chassis on delivery). Hang the PBX and secure it against being knocked off by screwing the (screw M3) chassis to the hanging element. Finally add the cover.



8.1. Earthing PBX

As has already been stated, good earthing of the PBX chassis is very important for the good functioning of the overvoltage protectors on the line modules. The PBX is naturally also earthed through the mains network (as a result of the earth wire – if it is connected to the plug). But this is not enough – for one thing in view of the danger that the PBX could be easily disconnected from the mains (the overvoltage from any line would then easily spread toe the chassis of the PBX and from there to



all other lines!), and the principle applies that earthing should be as good as possible. The ideal solution is thus a yellow-green copper wire with a cross section of at least 4 mm², leading for example from an earthing strip in the main switchbox. In an emergency it is necessary to at least earth it using such a wire (i.e., not disconnectable) from the nearest power socket (and check that it is correctly connected). Attach the wire to the chassis on the earth clamp on the right side of the chassis (marked with the earth symbol) and tighten well. We recommend that the earth always be connected before other cabling!!!

8.2. Connection to mains network

The detachable EURO-lead serves for connection to a regular socket. This makes it possible, if necessary, to rather elegantly make the lead longer with an extension EURO lead (used, for example, for connecting a PC and monitor). This extension also fits into the installation strip, for example 4x4 cm with other cables. The power lead can be run from the PBX through the hole in the power platelet with a hole and leads to the socket freely or through the strip.

8.3. Cabling for connecting system telephones

Every system telephone is connected to the PBX by a four-wire cable. The wires are marked A, B (call) and C, D (power + data both ways). For a system telephone to work, it is necessary not to swap the individual wires! If correct telephone cable is used (**four-wire cross cable**), this condition is met.

(you can tell if a cable is crossed by putting both transparent terminals next to each other pointing in the same direction, the coloured wire in both terminals are in the opposite order) If this connection does not work, the connectors probably do not have identical connection of terminals.

8.4. Cabling for connecting ISDN

According to the standard, the subscriber termination of line ISDN (NT1, NTBA (Network Termination Basic Access) is fitted with a connector RJ-45 with eight contacts. The module ISDN in the PBX is also equipped with the connector RJ-45, which can be used if the distance is not greater than 3 m. In this case it is necessary to use **four-wire non-crossed cable** with terminals RJ-45.

(you can tell if a cable is not crossed by putting both transparent terminals next to each other pointing in the same direction, the coloured wire in both terminals are in the same order)

If this connection does not work, the connectors probably do not have identical connection of terminals.



9. Minor servicing tasks

9.1. Replacement of lithium battery

The battery must be replaced if its voltage drops below 2.5 V. But we recommend that the battery be replaced at least once every three years, even if its voltage is correct. We recommend that the battery be replaced with the PBX switched off. Before changing the battery, we recommend saving the program of the PBX and the accounting data to a PC. After changing the battery, check the date, time and programme of the PBX, and if this data is not correct, perform a correction of the setting. In this case we recommend that this task be performed only when no one is using the telephone.

WARNING! Use only a tool made from insulating material for replacement!

WARNING!

Danger of explosion in case of incorrect battery replacement. It is only possible to replace a battery using one of the same or equivalent type according to the manufacturers recommendation. Always handle used batteries according to the manufacturer's instructions.

9.2. Setting music volume

On the motherboard there is a regulator for the volume of the external music source (connector J25). This task can be performed with the PBX switched on. In view of the miniature dimensions of the components, it is necessary to use a suitable tool (for example, precision screwdriver) and the appropriately light force.



10. Expanding PBX

The PBX can be expanded as desired by buying further modules up to the maximum configuration (48 lines). But it is necessary to be aware that every expansion constitutes intervention in the installation, and if done inexpertly it could threaten the functioning of the whole. In other words, the same level of knowledge as for the complete installation is required for this activity.

There exist two possible methods:

- 1. Complete reinstallation of PBX the advantage is the clarity of the procedure and optimum result, the disadvantage is the amount of work involved.
- 2. Addition of new modules without intervention in original part. The result is not always optimal, but there is less work. It is once again necessary to proceed according to the same rules which apply for the installation of a new PBX.

When expanding the PBX by either of the above methods, it is necessary to adhere to this procedure:

- 1. Before starting work, make backup copies of the PBX programming and accounting data.
- 2. Before starting work, check that all lines work.
- 3. Respect the warranty conditions.
- 4. Use only new or tested modules.
- 5. First of all decide on the location of modules on paper.
- 6. Mount all modules.
- 7. Add cabling.
- 8. After the actual installation, retest the function of all lines new and original.
- 9. It is always necessary to programme the new configuration again.
- 10. Test all functions which you have programmed.
- 11. Make another backup copy of the PBX programming.
- 12. Document all changes made.

11. Installation of front-end protection

If you have decided to install front-end overvoltage protection, we recommend that:

- You carefully consider which lines you will protect (air lines, external lines or all lines).
- You use protection which has significantly better properties.
- Locate front-end protection at the entry of the wiring to the building. You will thus gain the greatest effectiveness and you will also limit the possibility of induction overvoltage in other circuits in the building.
- Under extreme conditions use protection which can be replaced easily.



12. Technical parameters

Nominal mains voltage	110 - 230 V		
Tolerance of mains voltage +/- 10 %			
Nominal frequency	50 Hz		
Input	max. 90 VA		
Fuse	F4A/250V		
Climatic conditions			
Temperature range		+15+45 °C.	
Relative air humidity		Max. 85 % (40 °C)	
Classification of environment	– basic	Normal premises	
Operating position		Upright	
Dimensions of PBX		384 X 270 X 234 mm	
Weight		Max. 6,4 kg	
Internal line parameters			
Impedance of analogue input		600 Ω +/- 20 %	
Ringing voltage		45 V ~ / 50 Hz	
Line supply voltage		24 V	
Line current		Approx. 25 MA	
Number of connecting wires		2	
Type of connector		RJ-45 (PIN 4,5)	
Parameters of wiring for internal telephones			
Single wire resistance		max. 800 Ω	
A,B conductor capacitance		max. 0,5 μF	
Leakage current between conductors		min. 20 kΩ	

External line parameters			
Analogue input impendence		600 Ω +/- 20 % / ETSI	
Number of connected wires		2	
Type of connector		RJ-45 (PIN 4,5)	
16 kHz pulse receiver parameters			
Impedance of external line with 16 k impulse receivers	Hz tariff	/Z/ = 200 Ω +/- 20 %	
Min. evaluation level against 0 dB (775 mV / 200 Ω) at 16 kHz		-30 dB (selectable-10 dB)	
Min evaluated pulse		40 ms	
System telephone parameters			
Supply voltage		-24V	
Speech line impedance		600 Ω	
Number of connecting conductors		4	
Type of connector		RJ-45 (PIN 4,5 – 3,6)	
GSM parameters			
GSM band		GSM900/1800, GSM850/1900	
Voice transmission		EFR, FR (enhanced full rate, full rate)	
Receiver sensitivity		-104 dBm	
Transmitter power		2 W during pulse	
SMS support		MO, MT (receive and send)	
SIM card		Small, 3V	
Antenna connector		SMA	
ISDN S₀ parameters			
Interface type S ₀ - TE -		 for connection to public network 	
Protocol DSS1 –		EURO ISDN (w/o power supply)	
Connector for public network P-MP (p		oint – multipoint) – supports MSN	
configurable for connecting	P-P (poi	nt – point) – supports DDI	
Connection	4-wire (o	optional, terminated $2x \ 100\Omega$)	
Type of connector	RJ-45 (F	2IN 4.5 – 3.6)	

TELEKOMUNIKACE



DTMF dialling receive parameters		
Receiver sensitivity	-27 dB	
DTMF dialling send parameters:		
Frequencies	According to Q23	
Send level of lower frequency group	-10 dB to -6 dB	
Send level of higher frequency group	-8 dB to -4 dB	
Pulse dialling send parameters:		
Pulse duration	60 ms *	
Pause duration	40 ms *	
Pulse dialling receive parameters:		
Pulse duration	30 ms to 70ms	
Pause duration	30 ms to 70ms.	
FLASH send parameters	100 ms *	
FLASH receive parameters	90 ms150 ms *	
* Preset values, can be changed		
Modem detection parameters	min24 dB at 1300 Hz	
Fax detection parameters	min24 dB at 1100 Hz	
Dialling tone frequency	f = 425 +/-20 Hz	
Dialling tone level	-5 dB	
Nominal transmission attenuation:		
Internal connection	08 dB	
External connection	-0.5+1.5 dB	
here a DOODO O here to (make a superior)		

Interface RS232-C basic (galv. separate):		
Signals	RXD, TXD	
Transmission rate	9600 - 57600 bps	
Insulation strength against ground	500 V	



Notes:

Notes: