






General safety instructions	38	
Symbols used in this manual _____	38	
Importance of this manual _____	38	
Envisaged use _____	38	
Installer's qualifications _____	38	
Automatic gate safety elements _____	38	
Description of the product	39	
Elements of the complete installation _____	39	
General characteristics of the operator _____	40	
Main operator parts _____	40	
General characteristics of the operator _____	41	
Declaration of conformity _____	41	
Unpacking and content	42	
Unpacking _____	42	
Content _____	42	
Installation	43	
Necessary tools _____	43	
Initial conditions and checks _____	43	
Installing the operator _____	44	
Final preparation _____	53	
Maintenance and diagnosis of failures	54	
Maintenance _____	54	
Failure diagnosis _____	54	
Spare parts _____	54	
Scrap _____	54	

1 SYMBOLS USED IN THIS MANUAL

This manual uses symbols to highlight specific texts. The functions of each symbol are explained below:

⚠ Failure to respect the safety warnings could lead to accident or injury.

⌚ Work sequences or procedures.

📖 Important details which must be respected for correct assembly and operation.

📄 Additional information to help the installer.

♻ Information on care for the environment.

2 IMPORTANCE OF THIS MANUAL

⚠ Read this manual in its entirety before carrying out the installation, and obey all instructions. Failure to do so may result in a defective installation, leading to accidents and failures.

📄 Moreover, this manual provides valuable information which will help you to carry out installation more efficiently.

📖 This manual is an integral part of the product. Keep for future reference.

3 ENVISAGED USE

This device has been designed for installation as part of an automatic opening and closing system for swing gates.

⚠ This device is not suitable for installation in inflammable or explosive environments.

⚠ Failure to install or use as indicated in this manual is inappropriate and hazardous, and could lead to accidents or failures.

⚠ The installer shall be responsible for ensuring the facility is set up for its envisaged use.

4 INSTALLER'S QUALIFICATIONS

⚠ The installation should be completed by a professional installer, complying with the following requirements:

- He/she must be capable of carrying out mechanical assemblies in doors and gates, choosing and implementing attachment systems in line with the assembly surface (metal, wood, brick, etc) and the weight and effort of the mechanism.

- He/she must be capable of carrying out simple electrical installations in line with the low tension regulations and applicable standards.

- He/she must be capable of carrying out simple masonry work (digging of pits, channels, preparation of cement).

⚠ The installation should be carried out bearing in mind standards EN 13241-1 and EN 12453.

5 AUTOMATIC GATE SAFETY ELEMENTS

This device complies with all current safety regulations. However, the complete system comprises, apart from the operator referred to in these instructions, other elements which should be acquired separately.

📖 The safety of the complete installation depends on all the elements installed. Install only Erreka components in order to guarantee proper operation.

⚠ Respect the instructions for all the elements positioned in the installation.

⚠ We recommend installing safety elements.

📄 For further details, see "Fig. 1 Elements of the complete installation" on page 39.

1 ELEMENTS OF THE COMPLETE INSTALLATION




Fig. 1 Elements of the complete installation

▲ The safe and correct operation of the installation is the responsibility of the installer.

☞ For greater safety, Erreka recommends installing the photocells (4) and (10).

2 GENERAL CHARACTERISTICS OF THE OPERATOR

The VULCAN S operator is constructed to form part of a hinged gate automation system. Allows the requirements of standard EN 12453 to be fulfilled.


It comprises a metal casing, which contains a hydraulic pump and a drive piston.

VULCAN S operators are fitted with an exclusive safety system, patented by ERREKA.

This safety system is capable of detecting the collision of the gate with an obstacle, informing the control panel of this incident, in order to invert operation direction.

Hence, VULCAN S operators, along with the ERREKA control panels, allow the requirements of standard EN12453 to be met without the need for peripheral elements.

3 MAIN OPERATOR PARTS



C77A

- | | | | |
|---|-----------------------------------|---|---|
| 1 | Supports | 6 | Opening pressure adjustment screw |
| 2 | Ball and socket joint | 7 | Opening/closing pressure adjustment screw cap |
| 3 | Piston rod | 8 | Electrical connections cover |
| 4 | Piston rod cover | 9 | Discharge screw |
| 5 | Closing pressure adjustment screw | | |


Fig. 2 VULCAN S operator main parts

4 GENERAL CHARACTERISTICS OF THE OPERATOR

Model	General	Models -M
Power supply (V/Hz)	230/50	110/60
Intensity (A)	1	2
Power consumed (W)	230	220
Capacitor (μ F)	10	20
Protection factor (IP)	54	
Maximum force (N)	7.000	
Piston rod speed (mm/s)	10 (20 fast models -R-)	
Piston rod travel (mm)	VUS31: 265; VUS41: 400	
Lock	None self locking	
Mechanical slow down	No	
Safety system	Obstacle detection patented by ERREKA	
Service temperature ($^{\circ}$ C)	-10/+90 (-30/+90 models -F-)	
Duty cycles (%)	100	
Weight (Kg).	9.5 (short models); 11 (long models)	
Use	Intensive	



Limits on use



5 DECLARATION OF CONFORMITY

Erreka Automatismos declares that the electromechanical operator VULCAN S has been drawn up for use in a machine or for assembly along with other elements in order to form a machine in line with Directive 89/392 EEC and successive modifications.

The VULCAN S electromechanical operator allows us to carry out installations in line with the standards: EN 13241-1 and EN 12453.

The VULCAN S electromechanical operator complies with safety legislation in line with the following directives and standards:

- 73/23 EEC and successive modification 93/68 EEC
- 89/366 EEC and successive modifications 92/31 EEC and 93/68 EEC
- UNE-EN 60335-1

1 UNPACKING

1 Open the package and remove the contents from within.


♻️ Eliminate the packaging in an environmentally friendly manner, using recycling containers.

⚠️ **Do not leave the packaging within the reach of children or handicapped people, as it may cause injury.**

2 Check the content of the package (see figure below).

🔧 Should it be noticed that a piece is missing or deteriorated, contact the closest technical service.

2 CONTENT



I77A

- | | | |
|---|--------------------------|---------------------------|
| 1 Gudgeon axles caps | 7 Gland cover | 15 Front support bracket |
| 2 Safety washers | 8 Gland | 16 Front support |
| 3 Gudgeon vertical pin
($\varnothing = 12\text{mm}$, L = 37mm) | 9 Gland nut | 17 Safety ring |
| 4 Gudgeon | 10 Hydraulic motor body | 18 Ball bearing joint |
| 5 Gudgeon horizontal pin
($\varnothing = 10\text{mm}$, L = 57.2mm) | 11 Piston rod cover | 19 Ball bearing joint nut |
| 6 Gland cover screws | 12 Piston rod cover top | 20 Rear support |
| | 13 Piston rod cover tops | 21 Rear support bracket |
| | 14 Piston rod cover rods | 22 Faston terminals |

Fig. 3 VULCAN 5 Operator Content


1 NECESSARY TOOLS



Set of screwdrivers




Fixed wrenches




Socket wrench (8 mm)




Set of Allen keys



Pincers for Faston terminals




Marker pencil



Level



Tape measure



Welding machine

▲ Use the welding machine in line with the use instructions.

2 INITIAL CONDITIONS AND CHECKS

Initial conditions of the gate

▲ Check that the size of the gate is within the admissible range of the operator (see the technical characteristics of the operator).

▲ If the gate to be automated has a passage gate, install a safety device to prevent the operator from operating with the passage gate open.

☞ The gate must have an in-ground central stop and an in-ground stop in opening.

☞ The gate must be easy to manipulate manually, namely:

- This must be balanced, in order to ensure the effort made by the motor is minimum.
- There should be no stiffness throughout its travel.

▲ Do not install the operator in a gate which does not work correctly in manual operation, as this may lead to accidents. Repair the gate before installing.

Environmental conditions

▲ This device is not suitable for installation in inflammable or explosive environments.

▲ Check that the admissible environmental temperature range for the operator is suitable for the location.

Electrical power supply installation

▲ The electrical connections shall be made in line with the instructions in the control panel manual.


☞ The electrical cable section is indicated in: "Fig. 1 Elements of the complete installation" on page 39.



3 INSTALLING THE OPERATOR

☞ Horizontality of the operator

- ⚠ The operator must work horizontally: to do this, the supports must be positioned with a height difference of 19 mm.
- ☞ Check horizontality using a Spirit level.



☞ Assembly positions and dimensions

- ☞ For the correct operation of the operator, it is essential that the supports are positioned respecting the dimensions calculated, with regards to the gate and its rotation axis.
- ⓘ The dimensions are selected using either the table or the attached chart. The table indicates some specific cases, whilst the chart shows all the possible cases.


The assembly dimensions depend on the opening angle of the gate and the following factors:

- Type of operator chosen: short (Piston rod travel = 265mm) or long (Piston rod travel = 400mm)
- Opening of the gate inward or outward.

Hence there are four different cases, as explained below (each case is represented by way of its corresponding diagram, table and chart).




Short operator, inward opening



M77C

B (mm)



M10F

Opening angle	Dimension A	Dimension B
80°	155	130
85°	140	130
90°	140	120
90°	115	145
95°	125	125
100°	120	120
110°	105	120


i Use of the chart:

For a specific opening angle, multiple A-B pairs can be chosen. Generally, one of them will be determined by the characteristics of the installation (size of the pillar, presence of walls, etc).


- 1 Select the specified dimension in the chart.
- 2 Following the grid, move from the dimension to the line corresponding to the required opening angle.
- 3 Following the grid, move to the other dimension.



Short operator, outward opening



M77D




Opening angle	Dimension A	Dimension B
80°	150	135
85°	150	125
90°	100	155
90°	130	130
95°	120	130
100°	100	135
110°	95	125

i Use of the chart:

For a specific opening angle, multiple A-B pairs can be chosen. Generally, one of them will be determined by the characteristics of the installation (size of the pillar, presence of walls, etc).


- 1 Select the specified dimension in the chart.
- 2 Following the grid, move from the dimension to the line corresponding to the required opening angle.
- 3 Following the grid, move to the other dimension.

Long operator, inward opening



M77A

B (mm)



M10E

Opening angle	Dimension A	Dimension B
80°	250	180
85°	235	175
90°	200	195
90°	235	150
95°	220	155
100°	175	190
110°	190	155


i Use of the chart:

For a specific opening angle, multiple A-B pairs can be chosen. Generally, one of them will be determined by the characteristics of the installation (size of the pillar, presence of walls, etc).


- 1 Select the specified dimension in the chart.
- 2 Following the grid, move from the dimension to the line corresponding to the required opening angle.
- 3 Following the grid, move to the other dimension.



Long operator, outward opening



M77B



Opening angle	Dimension A	Dimension B
80°	200	235
85°	180	230
90°	165	225
90°	195	200
95°	160	215
100°	140	215
110°	140	195


i Use of the chart:

For a specific opening angle, multiple A-B pairs can be chosen. Generally, one of them will be determined by the characteristics of the installation (size of the pillar, presence of walls, etc).

- 1 Select the specified dimension in the chart.
- 2 Following the grid, move from the dimension to the line corresponding to the required opening angle.
- 3 Following the grid, move to the other dimension.


! Procedure

Position the front and rear supports




- 1 Attach the front (1) and rear (2) supports, keeping strictly to the dimensions shown in the previous section.
 - ▣ The installer should choose the support attachment system (welding, screwing, molding, etc) in accordance with the composition of the material to which the supports are attached (metal, concrete, etc).
 - ▣ Attach the supports on sufficiently robust structural elements.
- 2 Weld the support brackets (3) and (4) to the supports (1) and (2).
- ⚠ Carry out the welding with the operator withdrawn and at a distance. If not, the piston rod may become damaged from Welding splatter, which could lead to failures and oil leaks.

Mount the ball bearing joint and the gudgeon




- 1 Introduce the nut (1) in the ball bearing joint (2).
- 2 Thread the ball bearing joint-nut set on the piston rod (3).




- 3 Position the gudgeon (4) in its housing in the rear end cap (5).
- 4 Introduce the horizontal pin (6), crossing the gudgeon and the top.
 - ▣ Horizontal pin: $\varnothing = 10\text{mm}$, $L = 57.2\text{mm}$
- 5 Secure the pin using the safety washers (7).
- 6 Position the caps (8) to close the housing.

Mount the operator on the front support




- 1 Introduce the operator ball bearing joint (1) in the front support pin (2).
- 2 Secure the ball bearing joint using the safety washer (3).

Mount the operator on the rear support




- 1 Introduce the gudgeon (1) in the support (2).
- 2 Position the vertical pin (3), crossing the orifices of the gudgeon and of the support.
 ■ Vertical pin: $\varnothing = 12\text{mm}$, $L = 37\text{mm}$
- 3 Secure the pin using the safety washers (4).
- 4 Position the caps (5) to close the housing.

Mount the cover and the top




- 1 Introduce the rods (4) through the orifices of the top (1) and the internal cover guides (2).
- 2 Thread the rods in the front top of the operator (3) and tighten firmly.
- 3 Position the caps (5) in the holes in the top

Loosen the discharge screw



- 1 Once the operator is mounted on the supports, turn the discharge screw (1) once to allow the correct operation of the hydraulic system.
- ⚠ If you have to dismount the operator from its supports, first tighten the discharge screw in order to prevent the hydraulic fluid from leaking.


Mount the gland and introduce the cable



- 1 Introduce the cable (3) through the gland PG11 (1).
- 2 Position the gland in the end cap (4) and attach using the nut PG11 (2).
- 3 Crimp the Faston connectors in the electrical cables (5).



Connect the motor to the switchboard



▲ Before making any electrical connections, check the switchboard instructions manual.

☞ We recommend using switchboard VIVO-D101(M).


- 1 Connect the operator (VUS) to the switchboard.
- 2 Connect the capacitor (C) in cable connectors Turn 1 and Turn 2.
- 3 Connect the closing limit switch (FCC).
 ☞ The FCC allows the switchboard to distinguish between a collision with an obstacle and with a stopper on closing.
- 4 Connect the switchboard to the electricity supply.
- 5 Activate the power supply switch.

▲ Before carrying out any gate movement, ensure there is no person or object in the radius of action of the gate and the drive mechanisms.

- 6 Use the switchboard mini-pushbuttons (CLOSE-OPEN) to check the motor connections are correct (turning direction).
 ☞ If the turning direction is not correct, interchange the cables 2 and 3.


▲ Ensure the earth cable is properly connected.

Position the end cap and tighten the gland



- 1 Position the end cap (1) in its housing (2) and attach using the screws (3).
- 2 Tighten the gland (4) to ensure the electrical cable input (5) is seal tight.

Adjust the opening and closing force




▲ The opening and closing forces must be adjusted to fulfil standard EN 12453:2000 (for further details, please ask "Final preparation" on page 53).

- 1 Remove the cap (1) which covers the adjustment screws.
- 2 CLOSING FORCE: screw (2).
 - The "Closing force" is, more exactly, the force during the extension of the piston rod. In inward opening installations, it corresponds to the closing operation. In outward opening installations, it corresponds to the opening operation.
- 3 OPENING FORCE: screw (3).
 - The "Opening force" is, more exactly, the force during the retraction of the piston rod. In inward opening installations, it corresponds to the opening operation. In outward opening installations, it corresponds to the closing operation.
- 4 Replace the cap (1).

4 FINAL PREPARATION

Connections and checks



- 1 Carry out the installation and the connections for all the elements of the facility, in line with the control panel instructions.
- 2 Check that the mechanism is correctly regulated.
 - ▲ The opening and closing forces must be adjusted to respect the values indicated in standard EN 12453:2000, as shown in the attached chart. The measurements must be made in line with the method described in standard EN 12445:2000.
- 3 Check the operation of all the installation elements, especially the protection systems and the manual operation unlocking system.

User instruction

- 1 Instruct the user with regards to the use and maintenance of the facility and provide him/her with the use manual.
- 2 Point to the gate, showing that it opens automatically, and indicating how to operate it manually. Where appropriate, indicate that operation is using the remote control.

1 MAINTENANCE

- ▲ **Before carrying out any maintenance operation, disconnect the device from the power supply.**
 - ❗ If you have to dismount the operator from its supports, first tighten the discharge screw in order to prevent the hydraulic fluid from leaking.
- 1 Regularly check installation in order to discover any imbalance or signs of deterioration or wear. Do not use the device if any repair or adjustment is necessary.
 - 2 Clean and lubricate the articulations of the gate, so as not to increase the effort of the operator.
 - 3 Check that the transmitters and photocells, as well as their installation, have not suffered any damage from the weather or external agents.

2 FAILURE DIAGNOSIS

Problem	Cause	Solution
The operator does not make any movement when the opening or closing transmitters are activated	Absence of system power voltage	Re-establish the power supply voltage
	Defective electrical installation	Check that the installation does not present any short-circuits or cut-off points
	Defective control panel or control devices	Check these elements, seeing their respective manuals
By activating the opening or closing controls, the operator is enabled but the gate does not move	Defective capacitor	Check the state of the capacitor
	The assembly dimensions of the supports have not been respected.	Dismount the supports and then put them back in place, respecting the assembly dimensions
The gate moves in an irregular manner	The operator is not horizontal	Dismount the supports and then put them back in place, respecting the height difference of 19 mm
	The photocell detects an obstacle	Eliminate the obstacle and try again
	The resistance of the gate has increased when closing (or when opening)	Check the moving parts of the gate and eliminate the resistance
	The force of the operator during closing (or opening) is too low	Use the opening and closing force adjustment screws to increase the force when opening and closing
The gate cannot completely close (or open)	The assembly dimensions of the supports have not been respected.	Dismount the supports and then put them back in place, respecting the assembly dimensions

3 SPARE PARTS

- ▲ **If the operator needs repairing, go to an authorised assistance centre or manufacturer; never try to repair it yourself.**
- ▲ **Use only original spare parts.**

4 SCRAP

- ▲ **The operator, up until the end of its useful life, must be dismantled at its location by an installer who is as well qualified as the person who completed the assembly, observing the same precautions and safety measures. In this manner we will avoid possible accidents and damage to adjacent facilities.**
- ♻️ The operator must be deposited in the appropriate containers for subsequent recycling, separating and classifying the different materials in line with their nature. NEVER deposit it in domestic rubbish or in landfills which are not controlled, as this will cause environmental damage.