
Instructions for connecting a single proximity reader to a

central unit

Example of cabling a proximity reader to connector 1



Note: A 2-door extension board <u>can be added</u> to increase the number of doors to 4.


Recessed box


The proximity reader can be fitted optionally into a recessed box. Here are the sizes:





Page 1/2 V231 - 0040 - AB







Page 2/2 V231 - 0040 - AB