

CABLING FOR A DOOR CONNECT TO THE CENTRAL UNIT OR PANEL RELAY :



To best secure the opening of the door, connect the electric or magnet lock to the central unit's CRT relay then set switch No.2 to ON.

IMPORTANT: Proper operation and long-life are dependent on the fitting of the varistors supplied with the central unit

- 1. The varistor must be connected as close as possible to the electric lock or magnet
- 2. Free access times should be avoided for doors fitted with electric locks!
- 3. The varistor is 12 V.