

Ins-30071 Net2 desktop reader, proximity and magstripe USB

Technical Support



01273 811011



support@paxton.co.uk

Technical help is available: Monday - Friday from 07:00 - 19:00 (GMT) Saturday from 09:00 - 13:00 (GMT)

Documentation on all Paxton products can be found on our website - http://www.paxton.co.uk/

Desktop Reader

The desktop reader is designed to sit next to the PC. It is used for adding tokens to a Net2 system and also for identifying lost cards. Additional workstations can also have desktop readers.

With the Net2 software running, any new token presented above the desktop reader will cause the new user wizard to appear with the card number displayed. Additional user details can then be entered.

If the token is already known to the system, the relevant user's record will appear.



Installation

Plug the reader into a convenient USB port on the PC using the supplied USB cable.

Stop and then restart the Net2 server program. The device will now be available to the Net2 program.

This unit requires Net2 v3.09 or later software. Call Technical Support if you require a software upgrade.

Specifications				
Environment	Min	Max		
Operating temperatures - all items	0 °C	55 °C		
Waterproof			No	
Electrical	Min	Max		
Voltage	4.75V DC	5.25V DC	USB certified	
Current		100 mA		
Dimensions	Width	Depth	Height	
	145 mm	90 mm	37 mm	





Ins-30071 Net2 desktop reader, proximity and magstripe USB

Technical Support



01273 811011



support@paxton.co.uk

Technical help is available: Monday - Friday from 07:00 - 19:00 (GMT)

Saturday from 09:00 - 13:00 (GMT)

Documentation on all Paxton products can be found on our website - http://www.paxton.co.uk/

Desktop Reader

The desktop reader is designed to sit next to the PC. It is used for adding tokens to a Net2 system and also for identifying lost cards. Additional workstations can also have desktop readers.

With the Net2 software running, any new token presented above the desktop reader will cause the new user wizard to appear with the card number displayed. Additional user details can then be entered.

If the token is already known to the system, the relevant user's record will appear.



Installation

Plug the reader into a convenient USB port on the PC using the supplied USB cable.

Stop and then restart the Net2 server program. The device will now be available to the Net2 program.

This unit requires Net2 v3.09 or later software. Call Technical Support if you require a software upgrade.

Specifications				
Environment	Min	Max		
Operating temperatures - all items	0 °C	55 °C		
Waterproof			No	
Electrical	Min	Max		
Voltage	4.75V DC	5.25V DC	USB certified	
Current		100 mA		
Dimensions	Width	Depth	Height	
	145 mm	90 mm	37 mm	



The declaration of conformity is available on request. Contact details are provided at: http://paxton.info/596