

# MLIR07 Manual release kit for LIBRA garage door opener

## Installation manual

English





### SECTIONAL doors

- 1) Open the door wide.
- 2) Place the thin steel cable with end-ball in the pulling trolley (Fig. A).
- 3) Thread the steel cable into the rubber sheath and insert it in the eyelets of the anchoring door bracket (Fig. B).
- 4) Fasten the steel cable directly to the lock catch (Fig. C1) or to the door's handle by piercing it (Fig. C2).  
Make sure that the steel cable's tension is suitable to operate the release when twisting the handle.
- 5) In case, cut the extra cable away.



#### Warning:

Perform the manual release operation only when the door is not moving.



# MLIR07 Manual release kit for LIBRA garage door opener

## Installation manual

### COUNTERWEIGHTED doors (with adaptor arm PARC01)

- 1) Open the door wide.
- 2) Place the thin steel cable with end-ball in the pulling trolley (Fig. A).
- 3) Cut the anchoring door bracket (not used in case of counterweights balance door with adaptor arm) as shown in Fig. B and fix the bracket on the door beside the adapter arm.
- 4) Thread the steel cable into the rubber sheath and insert it in the eyelets of the anchoring door bracket (Fig. C).
- 5) Fasten the steel cable directly to the lock catch (Fig. D1) or to the door's handle by piercing it (Fig. D2).  
Make sure that the steel cable's tension is suitable to operate the release when twisting the handle.
- 6) In case, cut the extra cable away.

 **Warning:** Perform the manual release operation only when the door is not moving.

