

ERA PROTECT

SERIOUS ABOUT SECURITY

Unique Camera

ID:



INDOOR WIFI CAMERA
QUICK START GUIDE

TABLE OF CONTENT

| | |
|---|----|
| About your Indoor WiFi Camera | 3 |
| What's in the box | 4 |
| Exploring your ERA Protect Camera | 5 |
| Getting the best from your Indoor Camera | 6 |
| ERA Protect Indoor Camera placement tips | 7 |
| Motion alert and notification tips | 8 |
| Setting up your Camera | 9 |
| LED status | 10 |
| Specifications | 10 |
| Create your account | 11 |
| Adding your Indoor Camera to your ERA Protect account | 12 |
| Factory reset | 13 |
| Need support? | 14 |
| ERA Protect product guarantee | 15 |

ABOUT YOUR INDOOR WIFI CAMERA

See and hear what's happening inside your property from anywhere, on your smartphone or tablet. Your ERA Protect Indoor Camera alerts you when motion is detected. Watch live or review recordings in the cloud.



SAFE & SECURE

Your camera is protected using 128 bit SSL security encryption. Even if your camera is vandalised or stolen, your video clips are stored in the ERA cloud. Save your clips for 30 days by upgrading to ERA Protect Plus.



EASY TO USE


Your camera can be accessed using the ERA Protect app on your smartphone or tablet. You can also use the app to control your ERA Protect Alarm, Cameras, Doorbell or on its own. The settings are intuitive and adjustable to your own requirements.

WHAT'S IN THE BOX


Camera
& Stand



Power Supply



Fixing Kit



Reset Pin




Window Sticker



Quick Start
Guide



EXPLORING YOUR CAMERA



GETTING THE BEST FROM YOUR INDOOR CAMERA

Questions you may want to consider



What do I want to see in the field of view?



What kind of scenarios do I want to trigger a motion recording?



When do I want to have motion recorded?



Do I want a notification sent to me when motion recording is triggered?

Make sure when setting up your Camera, you:

- Position the Camera securely facing what you want to see.
- Ensure the motion detection set up matches your needs.

ERA INDOOR CAMERA PLACEMENT TIPS

- We recommend placing the camera no further than 10m/30ft away from your router; closer if there are obstacles in the way such as walls, doors or ceilings.
- Outside of this range, we recommend using a WiFi signal extender or repeater.
- The ERA Protect Indoor Camera is only compatible with the 2.4 GHz WiFi frequency.
- Make sure your camera is securely attached to the magnetic stand.
- Ensure the Camera is properly attached to the supplied stand before final installation and positioning.
- Compliance is only assured by using the included power supply.

MOTION ALERT & NOTIFICATION TIPS

Your ERA Protect Indoor Camera uses a sophisticated motion algorithm which detects when motion is happening, and can alert you instantly by push notification.

To receive alerts every time motion is detected*, you may wish to consider the following tips so that you achieve the best results and reduce the number of false alerts:



Active pets (or children!) may trigger the motion recording.



Movements near busy doors or windows may set off multiple notifications.



Depending on the location of the camera, you may trigger motion alerts due to reflections, shadows or sunlight.



You will not be able to use night vision if your camera is positioned to look through glass.


*In order to avoid multiple alerts for the same event, you will only receive an alert once every 15 minutes (per Camera).

SETTING UP YOUR CAMERA

It is important your ERA Indoor Camera Set up is configured according to your individual requirements. Once you have completed the set up process it is advisable to test the camera to ensure it is working.


1 Camera Location

If your chosen location for the camera is a wall. Attach the metal plate to the wall either vertically or horizontally where you want to position your camera.



2 Attach the stand

Attach the stand to the magnet connector on the rear of the camera.



3 Attach the power cable to the rear of the camera, and plug the power supply into a power socket and turn on.



LED STATUS

- Solid LED and 4 Night Vision LED's - Booting Up.
- Red Light Flashing (3 pulses) - Camera in Pairing Mode.
- Continuous Red Light Flashing - Firmware update.
- Red light flash - Will flash once when motion is detected, or settings have been changed.

SPECIFICATIONS

| | |
|------------------------|---|
| Power Requirements: | 5V DC Power Adapter Supplied |
| Night Vision: | LED's with IR Cut switcher up to 6m |
| Viewing Angle: | 86° Horizontal / 46° Vertical |
| Image Quality: | H.264 High profile, 1/3" CMOS Sensor, Full HD (1920*1080P) |
| Connectivity: | Wi-Fi 802.11 b/g/n 2.4GHz |
| Size (LxWxH) & Weight: | 65 x 112 x 33mm; 300g |

Create your account by downloading the ERA Protect iOS or Android app

Download the ERA Protect app  on your smartphone (search for “ERA Protect” on Google Play or the iOS App Store) then follow the steps on the screen.

If you're having problems finding the app please scan the QR code below with your smartphone.



Go to page 12 step 4 once you have set up your account.

SETTING UP YOUR INDOOR CAMERA

- 1 Power on the camera.
- 2 Wait for the camera to boot up, and then the status LED to pulse three times.
- 3 Go to the ERA Protect app, and select Add new from the Camera dashboard.
- 4 Select the ERA Protect Indoor Camera.
- 5 Follow the steps to connect the camera to your Wi-Fi network.

If the Wi-Fi set up fails, then you will need to put the camera into Pair mode. Please follow the steps below to do this:

- 1 Using reset pin, press the reset button for 5 seconds. The reset button is located on the underneath of the camera.
- 2 The camera will start booting up.
- 3 You can continue with the set up, once the status led starts pulsing three times.

FACTORY RESET

To factory reset your Camera, please do the following:

- 1 Open the ERA Protect app.
- 2 From the menu select Settings.
- 3 Choose your Camera.
- 4 Scroll to the bottom, and press Delete Camera.
- 5 Press OK to confirm you want to delete the Camera.
- 6 Close the app.
- 7 Using the Reset Pin, press the reset button down for 5 seconds. The reset button is located on the underneath of the camera.
- 8 Once the Status LED's pulses three times the camera is reset.

NEED SUPPORT?

Your ERA product is designed to be up and running in minutes. Please contact us for assistance or support. A more detailed installation and operation manual is available on our website.

Visit www.eraprotect.com
or phone us **0345 257 2500**



**ADD THE
ERA
PROTECT
PLUS**

WANT THESE GREAT FEATURES?

- 30 day rolling cloud storage for video recordings
- Access to 30 day activity log via the app
- Additional security features integrating your camera, with the ERA Protect Alarm, Doorbell and Cameras.

ERA PROTECT PRODUCT GUARANTEE

We at ERA firmly believe in the quality of our goods. Our technology achieves outstanding performance and durability and we can therefore offer, in addition to your statutory rights, an additional limited guarantee. In the event of any material defects in any product manufactured by us due to faulty design, materials and/or workmanship, and which arise following correct installation and during normal use in accordance with our instructions, as included in the product packaging, within the period of two years from the date of purchase, we will either repair, provide a replacement, substitute with equivalent product free of charge from our then current range or refund in full the amount paid for the product at point of purchase.

CONDITIONS

In order to take advantage of our guarantee, you must comply within the following conditions:-

1. This limited guarantee is not transferable and is extended only to, and is solely to the benefit of, the original purchaser of the product. Please retain your dated sales invoice as proof of purchase and forward this to us if you wish to make a claim under this guarantee.
2. Products must be installed, used and maintained in accordance with our instructions otherwise the guarantee will be invalidated.
3. The product must not be damaged or modified in any way nor must it have been subjected to any unauthorised repairs.

EXCLUSIONS

A full list of exclusions can be found within the full product guarantee, as detailed on our website www.eraprotect.com. This guarantee is in addition to your contractual and statutory rights and does not affect your statutory rights.

TO MAKE A CLAIM

Please contact Customer Support either by telephone on 0345 257 2500 or email support@eraprotect.com with full details of your claim. If your claim satisfies our Conditions and is not subject to any of our Exclusions, we will agree with you repair, replacement, substitution or refund of payment of goods. For full details of the claims process, please visit our website. *Terms and conditions apply.

RECYCLING AND DISPOSAL

Disposal of this product is covered by the Waste Electrical or Electronic Equipment (WEEE) Directive. It should not be disposed of with other household or commercial waste. At the end of the product's useful life, the packaging and product should be disposed of via a suitable recycling centre.

EC DECLARATION OF CONFORMITY

ERA hereby declare that this equipment complies with the essential requirements of the Radio and Telecommunications Terminal Equipment Directive 2014/53/EU. A copy of the EU Declaration of Conformity is available at www.eraprotect.com.

All devices, with the exception of the External Siren are suitable for mounting in dry interior locations only.

© ERA Home Security Limited. All rights reserved. All trade names are registered trademarks of respective manufacturers listed. App Store is a service mark of Apple Inc. Android and the "Google Play" logo are trademarks of Google Inc. Phone not included.



ERA Home Security Ltd
Valiant Way, Wolverhampton,
West Midlands, WV9 5GB

Customer Helpline: 0345 257 2500
www.eraprotect.com