

GTE KMG-2000 System Guide & Installation



Tel: 0845 054 5070 Fax: 0845 643 6814 Email: info@easygates.co.uk Web: easygates.co.uk VAT Registration Number 695769459 LTD Company registration 03051720



Installation instructions

Installation must be performed by a qualified professional and must observe all local, state, national and European regulations. Before starting installation, make sure that the product is in perfect condition. Laying, electrical connections, and adjustments must be done to "Industry Standards".

Packing materials (cardboard, plastic, polystyrene, etc.) are potentially dangerous. They must be disposed of properly and kept out of the reach of children Do not install the product in an explosive environment or in an area disturbed by electromagnetic fields.

The presence of gas or inflammable fumes is a serious safety hazard. Provide an over-voltage protection, mains/knife switch and/or differential on the power network that is suitable for the product and conforming to current standards.

The manufacturer declines any and all liability if any incompatible devices and/or components are installed that compromise the integrity, safety, and operation of the product. Only original spares must be used for repair or replacement of parts. The installer must supply all information regarding the operation, maintenance, and use of individual components and of the system as a whole.

Maintenance

To guarantee the efficiency of the product, it is essential that qualified professionals perform maintenance at the times and intervals required by the installer, by the manufacturer, and by current law. All installation, maintenance, repair and cleaning operations must be documented. The user must store all such documentation and make it available to competent personnel.

Warning for users

Carefully read the enclosed instructions and documentation. This product must be used for its intended purpose only. Any other use is improper and therefore dangerous. The information contained herein and in the enclosed documentation may be changed without notice, and are in fact provided in an approximate manner for application of the product. Easygates declines any and all liability in this regard.

Email: info@easygates.co.uk Web: easygates.co.uk



GTE KMG-2000 Overview & contents

The KMG-2000 system is used to measure forces exerted by automatic doors, gates & barriers used throughout the door & gate industry. The unit incorporates an on-board memory facility to store results collected whilst testing doors/gates to be later uploaded to computer to produce comprehensive reports.

The KMG-2000 suite contains the following components:-

KMG-2000 - Force testing device including toughened carry case

CABLE – male to male USB cable

CD – Software CD containing USB drivers and KMG-2005 software program

GTE Manual - Printed copy of GTE's own instructions for use of the device

* Certificate - Calibration/certification certificate for device (*If purchased)



(Please Note: Hardware/software requirements for connection of KMG-2000 to a PC are Windows operating system 95/98/ME/2000/XP/VISTA or Windows 7 PC with free USB port)

Optional Accessories

KMG-ARM – Extension set for measurements to EN12445 for gates (1 x 300mm, 1 x 500mm piece)



Email: info@easygates.co.uk Web: easygates.co.uk VAT Registration Number 695769459 LTD Company registration 03051720



Physical Connection & Software Installation

Remove tester and components listed above from packaging and connect the KMG-2000 to a free USB port on your computer. Insert the supplied CD-ROM in to your computers CD drive (if your computer does not have a CD drive copy the contents of the CD to a USB flash drive or download the software directly to your computer using an internet connection).Follow any on-screen prompts for installation of driver software and the KMG VD 2005 software package.

(For computers running Windows Vista, 7 or 8 it may be possible that the driver installation of the KMG-2000 device will fail at first installation of the program. If this occurs please re-start the computer and disconnect the KMG-2000 device from the USB port. Following the re-start, re-insert the CD or re-start the installation program and follow the on-screen prompts for installing the USB driver. Once complete, re-connect the KMG-2000 device to the USB port and device installation should complete.)

<u>PLEASE NOTE</u>: For computers running Windows 7 (or later) the latest version of KMG VD2005 (ver. 5.5) must be downloaded and installed following the successful installation of the CD version supplied. To download the correct version for operation with Windows 7 (or later) please visit <u>http://www.gte-industrieelektronik.de/material/KMG-VD2005-V5.5.exe</u>

Specifications:

Current supply: Current consumption: Interface:	integrated rechargeable batteries (2 x 1,2V NiMH), recharging via USB 20 mA USB
Internal memory:	500 single measurements (= 166 norm measurements)
Range of temperature:	-10 +60°C
Relative humidity:	20 - 90 % r.F. (not condensing)
Dimensions of contact area:	80 mm Ø, height: 50 mm
Overall dim. (incl. handle):	310 x 80 x 50 mm (<i>I x b x h</i>)
Weight:	1400 g
Measuring range:	25 N - 2000 N
Accuracy:	typ. ± 1% (full scale)
Spring (as mech. filter):	500 N/mm
Rising- / falling time:	≤ 5 ms

Email: info@easygates.co.uk Web: easygates.co.uk



Software Customisation & Configuration

Start the KMG VD 2005 software program, then click on "Options" & then "Company Data"



The following Screen will be displayed, fill-in your details and insert a company logo (if desired) and click "Save"

🔟 Company data		x
- Company adress	Company image	
Statements appear in printout:		
Easygates Ltd	N	
Unit 16 James Scott Road	SEacy Cate	c
Halesowen	SLasyGate	2
West Midlands		
B63 2QT		
Engineer: S Roddy	Change Picture Delete Pictu	ıre
	<u>Save</u>	el

To configure the software to your KMG-2000 device click on "Options" and then click "Options"





Easygates Ltd Unit 16 James Scott Road Halesowen, West Midlands B63 2QT

Gates & Railings - Automation - Access Control - Electrical

Adjustments			 			
General	Com	Existing	In Use	KMG-VD		1
Colours	Com-4					_
Language	Com-5					
Limiting values	Com-6					
KMG Connection	Com-7					
	Com-8					
	Com-9					
	Com-10					
	Com-11					
	Com-12					
	Com-13					Ξ
	Com-14					
	Com-15					
	Com-16					
	Com-17					
	Com-18					
	Com-19					
	Com-20			✓		L

Click on the "KMG Connection" tab and check that your KMG-2000 device is listed next to a "Com" port and the tick is showing next to the device, click "Ok". If the device does not appear re-check the driver installation or Windows device manager.

Device Measurement Data Transfer

Following successful completion of a series of tests on a gate/door the device will need to be connected to a computer and the measurement series transferred. To accomplish this power on theKMG-2000 device and connect it via the supplied USB cable to your computer, then start the KMG VD2005 software program.

Click on "KMG" and then "Load all measurements"



The KMG device transfers all measurements in its memory to the software and lists them in the left hand column below the navigation column.



Once all measurement sets are transferred the data file needs to be saved. To accomplish this click on "File" and then "Save As" from the menu.

Ĺ	KM	IG 2010 - Analysis		
	<u>F</u> ile	KMG Options Diagram Window	<u>I</u> nfo <u>?</u>	
	Ľ	Create New Series of Measurements	Ctrl+N	e
7	2	<u>O</u> pen	Ctrl+0	
	H	Save	Ctrl+S	\vdash
	ġ	Save <u>a</u> s	Ctrl+U	
		Expor <u>t</u> Measurement		ľ
		Expor <u>t</u> Measurement Printer <u>S</u> etup		
		Export Measurement Printer Setup Print	Ctrl+P	
	D 49	Export Measurement Printer Setup Print Exit	Ctrl+P	

The default format for saving the file provides the name of the device (KMG) and the date (2012_12_06) and the type (*.dat). Unless you have specific requirements (i.e. customer name) save the file in this format. The files are saved by default to the KMG folder on your computers hard disk.

🔟 Save as		lugite	23				
OO - 📜 « Acer	(C:) Program Files (x86) KMG	► ► ► Search KMG	٩				
Organize 🔻 New	folder		!≕ ▼ 🔞				
☆ Favorites	Name	Date modified	Туре				
🧮 Desktop	📔 driver	30/11/2012 14:19	File folder				
🗼 Downloads	📔 Temp	06/12/2012 12:01	File folder				
🗐 Recent Places	KMG_2012_11_30_05	30/11/2012 15:13	DAT File				
=	KMG_2012_11_30_06	30/11/2012 15:20	DAT File				
词 Libraries	KMG_2012_11_30_08	30/11/2012 15:34	DAT File				
Documents							
J Music							
Pictures							
🚼 Videos							
🤣 Homegroup							
	•	III	•				
File name: K	File name: KMG_2012_11_30_08						
Save as type: R	ecordset (*.dat)						
Hide Folders		Save	Cancel				

Email: info@easygates.co.uk Web: easygates.co.uk



** To Open a saved Measurement set using the Project browser you must click on the "File" and then "Open" option and then select the measurement set file (e.g. 2012_12_06) you created earlier when transferring data form the KMG-2000 device.

Copen recordset								
Correction of the second secon								
Organize 🔻 New folder 🛛 😨								
Desktop	*	Na	ame		Date modified	Туре		
Downloads			driver		30/11/2012 14:19	File folder		
			Temp		06/12/2012 12:17	File folder		
🗎 Libraries] KMG_2012_11_30_05		30/11/2012 15:13	DAT File		
Documents] KMG_2012_11_30_06		30/11/2012 15:20	DAT File		
-) Music	н		KMG_2012_11_30_08		30/11/2012 15:34	DAT File		
] Test Gate 1		03/12/2012 17:06	PRT File		
Videos			test		30/11/2012 15:08	PRT File		
nt Homegroup								
💻 Computer								
🚢 Acer (C:)								
👊 Network	Ŧ	•		III		Þ		
	ile n	ame:	KMG_2012_11_30_08	•	File (*.prt;*.dat;*.m	es) 🔻		
					Open	Cancel		

With the measurement file open it will display the measurement sets in the project browser, these cab now be "dragged and dropped" in to the corresponding measurement locations in your record set.

TE KMG 2010 - Analysis								
File KMG Options Window Info 2								
	Series of	measurements	Graphic					
	C:\Program Files (x86)	KMG\Test Gate 1.prt						
ITHELP2005	Standard:	Gate construc	otion:					
KMG 2012 11 30 05	EN 12445	Ŧ						
		Distance 50	Distance 300	Distance 500				
KMG 2012 11 30 08	ME Closed: Bottom	Standardised measurement-1	Standardised measurement-2	Standardised measurement-3				
— 📻 КМG2010	ME Closed: Middle	Standardised measurement-4	Standardised measurement-5	Standardised measurement-6				
	ME Closed: Top	Standardised measurement-7						
Test Gate 1 🚽								
< F	AE1 Closed: Bottom							
	AE1 Closed: Middle							
Test Gate 1.prt	AE1 Closed: Top							
Protocol								
Hemarks	ME Open: Bottom							
Standardised measurement 2	ME Open: Middle							
Standardised measurement-3	ME Open: Top							
Standardised measurement-4								
Standardised measurement-5	AE2 Open: Bottom							
□ Standardised measurement-6	AE2 Open: Middle							
Standardised measurement-7	AE2 Open: Top							

For support please call 0845 054 5070 Many thanks for your purchase.

Email: info@easygates.co.uk Web: easygates.co.uk VAT Registration Number 695769459 LTD Company registration 03051720