

New Style Mechanical Stop for all ELI250 Motors - ZZELI25

1



The Stop Kit will consist of:
1 x linkage arm
2 x 60 x 8mm threaded rod
2 x Linkage locking nuts
2 x Domed head Allen key bolts
2 x 15 x 4mm self threading screws

2




Screw the 60 x 8mm threaded rod into the turrets on the underside of the linkage arm as shown above.

3



Grease and Insert the linkage locking nut into the gearbox rotation lever from the underside as shown

4



Grease and Insert the linkage locking nut into the load lever arm from the underside as shown above

5



Fit the linkage arm to the load lever and the gearbox rotation arm. Grease the threads and fit the domed Allen head screws

6



With the 19mm spanner hold the linkage locking nut on the underside of the load lever and the gearbox rotation arm. Tighten the two domed Allen key bolts to fix the linkage arm in place

7



Adjust the VRO & VRC so that the gate stops in the required open and closed position.

Once this has been completed screw down the 2 x 15x4mm locking screws which will secure the VRC and VRO threaded rods in place.